

General Visual Keyboard Manual



CATALOGUE

1. Summary	1
1.1 Notice	1
1.2 Function and Characteristic	1
1.3 Technical Data	1
2. Keyboard Connection	2
2.1 Keyboard Interface Instruction	2
2.1.1 Rs422 and Rs485	2
2.1.2 Power Supply Port	2
2.1.3 Rs232 EIA Interface	2
2.1.4 CVBS Interface	2
2.1.5 USB Interface	2
2.1.6 VGA Interface	2
2.2 Matrix Connection	3
2.2.1 RS422 Remote Connection	3
2.3 Connect with The Dome Directly	4
2.4 Connect DVR	4
2.5 The Connection of The Keyboard in The System	5
3. Keyboard operation manual	6
3.1 Current-carrying to keyboard	6
3.2 LCD	6
3.3 Joystick controls dome	6
3.4 Change object dome	7
3.5 Control dome lens	7
3.6 Set dome function	7
3.6.1 Preset	7
3.6.2 Scan	7
3.6.3 Pattern	7
3.6.4 Tour	7
3.7 Call dome main menu	8
3.8 SDI and CVBS video output switch	8
3.9 Battery display setup	8
3.10 Control matrix	8
3.10.1 Switch dome in order	8
3.10.2 Call matrix main menu	8
3.10.3 Confirm after program	8
3.10.4 Change object monitor	8
4. Keyboard control	9
4.1 keyboard index setting	9
4.1.1 Set ID number	9
4.1.2 Set the baud rate	9
4.1.3 Set password	9
4.1.4 Joystick calibration	10
4.1.5 Multi keyboard state	11
4.2 Dome setup	11
4.2.1 Set dome preset	11
4.2.2 Set dome scan	11
4.2.3 Set dome pattern	12
4.2.4 Set dome tour	12

4.3 Alarm box control-----	13
4.3.1 Set the alarm input channel status and the alarm spot -----	13
4.3.2 Set alarm ON/OFF status and alarm reset time-----	13
4.3.3 Manually reset alarm input-----	14
4.3.4 Resume the factory default setting -----	14
4.4 Protocol setting-----	14
4.4.1 Pelco matrix model-----	14
4.4.2 Directly control model-----	14
4.4.3 DVR control model -----	15
4.5 Keyboard information display-----	15
4.6 Exit keyboard menu -----	15
5. Appendix -----	16
5.1 Rs485 Bus Basic Knowledge -----	16
5.2 Keyboard shortcut operation manual-----	17
6. Keyboard Menu Index -----	18

1. Summary

It is a portable HD visual 3-axis keyboard, can better control the integrate speed dome camera with various protocols, matrix and DVR; support 4 keyboards at the same time. 8-inch HD TFT LCD screen and the flip design, the user can easier control and provide the best visual sense.



1.1 Notice

- Please read the manual carefully and reserve it.
- Please advert to the notice in manual.
- Please don't place the keyboard in the moist place.
- Please don't close up the keyboard to exothermic object for long time.

1.2 Function and Characteristic

- With the 8-inch HD TFT LCD screen, this can display the real time image from the camera.
- Auto compatible with NTSC and PAL.
- English-Chinese OSD menu, easier to set up system parameters.
- SDI Input, can display the SDI image on the silkscreen directly
- Built-in SDI-HDMI auto switch device. HDMI output interface. .
- Support VBS/VGA, 800 x 600 display resolutions.
- Can control many brands of speed domes and DVR systems like Dahua, HikVison, Pelco matrix.
- Expandable interfaces can meet the different market requirements.
- Low power consumption, about 1.5W in standby mode.
- Flip design can provide the best visual sense.
- Built-in rechargeable batteries (optional)

1.3 Technical Data

- ◆ Electrical
Input voltage: DC12V
Rated power: 7.2W
- ◆ Communication
Communication interface: RS485 × 1, RS422 × 1, RS232 × 1
Communication frequency :
2400Bps ,4800Bps ,9600Bps,19200Bps
Communication distance: 1.2km
(RS485 and Rs422 can achieve it)
- ◆ Battery specification
Ni-MH battery:900mAh 9.6V
Charging time: Approx 4.5 hours
Charging current: 220mA
Battery life: 1 hours (battery completely charged)
- ◆ Operational environment
Operating temperature: -20°C ~ +50°C
Relative humidity: less than 90%
- ◆ Physical property
L × W × H = 290 × 191 × 95 (mm)
Weight: 1.6kg (Net Weight)

2. Keyboard Connection

2.1 Keyboard Interface Instruction

There have following interfaces on the back of the keyboard: RS232, RS422, and RS485, which can connect and control various peripheral equipment.

2.1.1 RS422 and RS485 interface

RS422 and RS 485 interface are on the 6bit ribbon cable connection of the keyboard. Rs485 (Tx+,Tx-) can connect with the dome when the keyboard controls the dome directly; RS485 (Tx+,Tx-) can connect with DVR and other keyboards when keyboard controls the dome by matrix; Rs422 (Tx+,Tx-) is sending the signal, RS422(Rx+,Rx-) is receiving the signal, both of which can connect with matrix ,DVR and so on.

Power switch button: cut-off power supply/ activate power supply

2.1.2 Power Supply Port

Power supply is DC12V.

2.1.3 RS232 Interface

To expand the functions and controlling like picture processor, DVR, PC and so on.

2.1.4 CVBS Interface


To receive the video signal of the camera; also can switch the video to receive multichannel camera video.

2.1.5 USB Interface


For SDI signal (1080i60/720p60/1080i50/720p50/1080p30/1080p25and etc.)

2.1.6 VGA Interface

Keep reserve for future expansion in function requirements.



Picture 2-1.1



Picture 2-1.2

2.2 Matrix Connection

The keyboard can control PELCO matrix CM6700, CM6800. Below we set an example “the connection between keyboard and PELCO matrix CM6700” to explain it. RS422 (REMOTE KEYBOARD(S)) in the back of CM6700 matrix connects with RS422 in keyboard, the max distance is 1200m.

2.2.1 RS422 Remote Connection

RS422 connection line, one end connects with RS422 interface (“REMOTE KEYBOA-RD(s)”) of CM6700 matrix, the other end connects with Rs422 in the keyboard, keyboard RS422 (Tx+ Tx-) corresponds with matrix RS422(Rx+ Rx-).




Rs422 remote connection, the maximum distance between the keyboard and the matrix is 1200m.

2.3 Connect with The Dome Directly


Keyboard connects with dome by RS485 directly. RS485 interface is on the switchboard of pendent hanger of the upper cover of the dome. It can be found that there are 4 Pin control/power sockets and the corresponding interface according to the above mark when you turn the metal button inside the hanger and the hanger of switchboard. There are different connection ways according to the domes which produced by the different manufacturers. Please be in strict accordance with the installation manual.

2.4 Connect DVR

The keyboard can connect DVR and dome by Rs422 interface, the keyboard Rs422 (Rx+, Rx-) Can separately connect DVR Rs485 (A+, B-) Rs422 (Tx+, Tx-) and dome Rs485 (A+, B-)



Picture 2-3.1




Picture 2-4.1

2. 5 The Connection of The Keyboard in The System


Keyboard controls the alarm box, and connects the dome by the alarm box. The details please see the alarm box user manual. Every alarm box only can connect one camera.

The keyboard controls the matrix, then controls the domes indirectly by the matrix (see to the picture2-5.1). When unconnect with the matrix, the keyboard controls the dome directly (see to the picture 2-5.2).



Picture2- 5. 2

when unconnect with DVR, the keyboard controls the dome directly Keyboard and camera may control each dome by parallel connect to Rs485 Bus and each keyboard may control each dome. This way is required to have a main keyboard(the main keyboard ID set as 1), the Baud rate of keyboard is set as 9600bps.(sees to the picture 2- 5 .3)




Picture2- 5.1

As the previous picture shows, keyboard and keyboard connection or keyboard and computer connection set as Rs232, when their distance is more than 20m, suggest that set it as Rs485.




1. A line of Rs485 may control up to 32 main controlling and under controlling equipments, so a keyboard which controls the dome directly may connect up to 31 domes.

2. The system may connect up to 4 keyboards at the same time, and the four keyboards ID are different.



Picture 2-5.3



Picture 3-1.1

3. Keyboard Operation Manual

This passage mainly describes the operation ways of keyboard, it needs to especially explain that different systematic platform has not the same operations, and different systematic platform may have some particular requirements and operations, please operate it to combine with the operation manual of dome and matrix.

3.1 Current-carrying to keyboard

When electricity to keyboard, the keyboard will auto-test the version number, keyboard ID, baud-rate, protocol, and object dome and object monitor will auto-set as 1, and these information will display in the LCD.



1. when the keyboard is initializing, should be make the joystick to return to 0, not to pull or tilt the joystick.

3.2 LCD

LCD display is used to display the basic information like model, ID, object dome, object monitor ID, baud rate etc, also display the input command and joystick operation in the bottom of the LCD. See (3-1.2),

Press " Ent " button for 3 sec, can manually turn on/off LCD.

Press " Shit " button for 3 sec, can manually turn on/off the character displayed on LCD.

Firmware		V1.03
Keyboard	ID:	001
Camera	ID:	002
Monitor	ID:	001
Protocol:		Pelco Matrix
Baudrate:		9600bps

Picture 3-1.2

3.3 Joystick controls the dome

Joystick has two functions, one is manually controlling dome rotation, the other is setting controlled object menu.

- Tilt joystick at any directions, the dome will rotate in correspondence with directions, at the same time, LCD displays the information as lower right corner shows "", they respectively reflects tilt up, tilt down, tilt right, tilt left. If the joystick tilts upper right corner, the screen will display such information "". The joystick return to the primary location, and the dome immediately stop to rotate.

- The joystick tilt up means choosing previous menu, which is down means choosing next menu if it is used to set the menu; the joystick is right means entering the next menu or reserving setting after setting, which is left means exit or stop reserving.

- The more heavy is the gradient of joystick, the more fast speed the dome rotates. By control the gradient of joystick, to control the rotation speed of dome.

- Rotate the joystick cap may adjust the focus of lens, to rotate in clockwise, the camera lens is Tele, at the same time there is "" displays in the LCD; the camera rotates in counter clock wise, the lens is wide, at the same time there is "" displays in the LCD.

3.4 Change object dome

【N】 + 【Cam】

【N】 reflects numeric key(Do not explain it again), input the dome ID, Press **【Cam】** to change object dome.

3.5 Dome lens control

Zoom control:

Press **【TELE】** ,lens zoom tele (the multiple of lens increase), leave to stop.

Press **【WIDE】** , lens zoom wide (the multiple of lens reduction), leave to stop.

User may control the zoom by rotating joystick.

Focus control:

Press **【FAR】** manually far focus, to make the far object more legible, leave to stop.

Press **【NEAR】** manually near focus, to make the

In usual situation, the camera is in the status of auto focus, user may operate manual focus to run other operations by the two keys, and the camera will automatically resume to auto-focus.

Iris control:

Press **【OPEN】** manual Iris increase, Iris is max, the screen will show white, leave to stop.

Press **【CLOSE】** manual Iris reduction, Iris is min, the screen will show black, leave to stop.

3.6 Dome function operation

3.6.1 Preset

- Set preset: **【SET】 + 【N】 + 【Preset】**

- Call preset: **【N】 + 【Preset】**
【N】 reflects preset number.

3.6.2 Scan

- Set left limit: **【SET】 + 【1】 + 【Scan】**

- Set right limit: **【SET】 + 【2】 + 【Scan】**

- Run scan: **【1】 + 【Scan】**

If change the speed of scan, should enter into menu setup.

3.6.3 Pattern

- Set pattern path: **【SET】 + 【N】 + 【PATTERN】 + Path + 【SET】 + 【0】 + 【PATTERN】**

Press **【SET】** , input pattern NO. (1-4) ,

press **【PATTERN】** to enter tour setup, the dome

records a series of motions, when end up, press **【SET】** , then press **【0】** ,then press **【PATTERN】** , the pattern setup is finished.

- run pattern: **【N】 + 【PATTERN】** Input pattern number (1-4) , press **【PATTERN】** , run pattern.

3.6.4 Tour

Run tour: **【N】 + 【TOUR】 / 【TOUR】**

near object more legible, leave to stop.

Press tour number, press **【TOUR】** , run tour. If system has only a tour, press **【TOUR】** directly.

Set tour must enter menu setup.

3.7 Call the dome main menu

【9】 + 【5】 + 【Preset】 : input 95, then press **【Preset】** to call the main menu of object dome, and the menu is displayed in the object monitor. About how to set the dome menu by keyboard, Please refer to the dome Operation manual.

3.8 SDI and CVBS video output switch

The SDI video will be displayed in priority when there are SDI and CVBS video output at the same time. Press **【shi】 + 【2】 + 【Enter】** to switch to sole CVBS output mode, even there is no CVBS video signal output, the SDI video also can't be displayed either. Press **【shi】 + 【1】 + 【Ent】** to resume the priority of SDI video signal output.

3.9 Battery display setup

If the keyboard is equipped with battery ,please enter the OSD keyboard setup→ Battery label:

When choose “on ” : 3 auto-cycle charging symbol will display on the bottom right corner of the screen:
 “    ”

The bottom right corner of the keyboard screen will show: “  . When the battery is completely charged. If not, there will show: “  ”

When choose “off ” : charging symbol will not be displayed.

- 1 .When the keyboard is only powered by the battery, the screen will be auto shut-off to reduce the consumption after a period time of idle. Press any keys or Move the joystick to activate the displaying. When the keyboard is connected to a power source directly, the screen will not auto shut-off anymore.
2. After a period time of use, the battery will becharged again when the keyboard is connected to power source directly.
3. The battery has a little discharging current which is 25uA.



3.10 Control the matrix

3.10.1 Switch the domes in order

The matrix connects sixteen domes, and switches the dome to previous and next dome. Series No.,date and time will display in the monitor..

【PREV】 : switch to previous dome. Press **【PREV】** , switch to previous dome in single step; Press **【PREV】** to hold it for 2s, and jump sixteen domes of the connection matrix in previous order. Press **【Stop】** to stop to switch.

【NEXT】 : switch to next dome. Press **【NEXT】** to switch the next dome in single step; press **【NEXT】** to hold it for 2s, and jump the sixteen domes of the connection matrix.

【Stop】 : switch continuously, press **【Stop】** to stop to switch.

3.10.2 Call main menu of matrix

【Shift】 + 【Set】 : call the main menu, and the menu will be displayed in the object monitor. How to set the matrix menu by keyboard? Please refer to the matrix operation manual.

3.10.3 Confirm after program

【ENTER】 : after the matrix is programmed, press **【ENTER】** , reflects confirm after program, as for the detail program, please refer to the matrix operation manual.

3.10.4 Change object monitor

【N】 + 【MON】

Input the monitor ID, then press **【MON】** , the image and the menu of the dome that controlled by keyboard will display in the object monitor.




As the keyboard is working in Pelco matrix mode (refer to DIP switches setting),the keyboard can directly control the dome or the monitor by matrix. just work under pelco matrix mode, may carry out the command of controlling matrix.

4、 The Keyboard Menu Controlling

The keyboard menu controlling

Press **【Set】** ,keep 2 seconds; Got the main menu, the LCD display as below.(See to picture 4.1-1)all menu setup should call main menu.

Press numerical key or move the joystick up and down after entering the main menu, which can enter the relevant menu setting.



Picture 4.1-1

Saving Setting

Choose relevant numerical keys in according to the menu hint, then can enter relevant function setting;

Press **【Enter】** and reserve; LCD will display

“success” after finishing the setting successfully.

Returning previous menu


Press **【Prev】** ,or move the joystick leftwards, then return the previous menu.

4. 1 Keyboard ID Setting

4. 1. 1 Setting keyboard ID

1. Enter main menu


LCD display(See to picture 4.1.1-1)



Picture 4.1.1-1

2. Press **【1】** then choose keyboard setting


LCD display (See to the picture 4.1.1-2)



Picture 4.1.1-2


3. Press **【1】** to choose keyboard ID setting

LCD display (Sees to the picture 4.1.1-3)




Picture 4.1.1-3

Press the relevant numerical key (1-64); press **【 Enter 】** to confirm. The screen display (See to picture 4 . 1 . 1 - 4) , which means operating successfully。



Picture 4.1.1-4

The screen will show **【 Error 】** if putting the numerical key which are exceed the ID scope (1-64) (Sees to picture 4.1.1-5)



Picture 4.1.1-5

4. Press **【PREV】** or move the joystick leftwards then go back gradually

The factory default ID of the keyboard is 1; The ID Number must be 1 if the single keyboard works; It can connect up to 4 keyboard when working on line, but make sure there is only a keyboard ID set as 1,otherwise all the online keyboards can not work normally.



4. 1. 2 The keyboard baud rate setting


Enter menu (LCD display sees to the picture 4.1.1-1)

Press **【1】** to set the keyboard

LCD display (sees to the picture4.1.1-2)

Press **【2】** to set the keyboard baud rate.

LCD Display (Sees to the picture 4.1.2-1)



Picture 4.1.2-1

There are 4 kinds of baud rate:2400bps/4800BPS/9600BPS/19200BPS,user choose one accordingly. then press “ Enter” . The screen display (sees to the picture 4.2-4) It means the operation is success.Then Press **【Prev】** or move the joystick leftwards to go back.




Must be used 9600BPS when connecting with the matrix DVR; and must be used 9600BPS or 19200bps when connecting the keyboard online.

4.1.3 Setting password

Enter OSD menu, LCD will display as Picture (4.1.1-1) shows:

Press **【1】** to choose keyboard setting, LCD will display as Picture 4.1.1-2 shows.

Press **【3】** to choose password setting, LCD will display as Picture 4.1.3-1 shows.




Picture 4.1.3-1

Press **【 1 】** to choose of password setting, as choosing 1, LCD will show "SUCCESS", it means entering OSD menu need to input password; as choosing 2, LCD will show " SUCCESS", it means entering OSD menu no need password. (As picture 4.1.3-2 shows)



Picture 4. 1. 3-2

Press **【2】** to choose modify password . LCD will display as picture 4.1.3-3 shows



Picture 4. 1. 3-3

Firstly input the initial password " 892226", press "ENTER", the cursor will jump to the second row,then input the new password, press "ENTER", the cursor will jump to the third row, confirm your new password again, press "ENTER",, LCD will show "SUCCESS",and back to the menu.

"892226" as super password, as the user forget password and can't enter OSD menu,

NOTICE at this time user can use if password to enter it.

4. 1. 4 Joystick Calibration

User can enter the joystick menu for calibration, the joystick must stay with natural status when calibration.

Enter the main menu.

LCD display.(sees to the picture 4.1.1-1)

Press **【1】** To choose the keyboard setting.

LCD setting. (sees to the picture 4.1.1-2)

Press **【3】** to enter Joystick Calibration.

LCD display (sees to the picture 4.1.3-1)

Joystick is free then
Press Enter

Picture 4.1.4-1

Press **【 Enter 】** then finish the operation
The screen display (see to the picture 4.1.3-2)

Success!

Picture 4.1.4-2



As joystick calibration, make sure the joystick be on natural status.

4.1.5 Multi-keyboard Connection state setting

Enter into OSD menu, LCD will display as Picture 4.1.1-1 shows.
Press **【1】** to set the keyboard.
LCD will display as Picture 4.1.1-2 shows. Press **【4】** to set multi-keyboard connection state setting. After selecting **【Multi keyboard state】**, tilt up/down the joystick to set the state as “ON” or “OFF”, the default setting of keyboard is OFF, as it set as ON, it can support multi-keyboard work, there is non-interference between them, one group can support 4 keyboard mostly, as Multi-keyboard state is opened, if there is only a keyboard to work, the keyboard address must be set as 1, or the keyboard can't be controlled.



In multi-keyboard state the baud rate of each keyboard should be set as 9600bps.

4.2 2 Dome function setting

Entering OSD menu, press **【2】** to enter dome function setting. As picture 4.2-1 shows

1、 Set dome preset
2、 Set dome scan
3、 Set dome pattern
4、 Set dome tour

press PREV to back

Picture 4.2.1

4.2.1 1 Preset

Press [1] to choose preset, LCD will display as Picture 4.2.1-1 shows.

1、 Save preset
2、 Show preset
3、 Clear preset

press PREV to back

Picture 4.2.1-1

Press [1] to save preset: by operating joystick and adjusting magnification to choose objective image, then choose [1] to save preset, input preset Number (1-128), you can set 128 preset at most. LCD will display as Picture 4.2.1-2 shows.

1.Preset num:
(1-128)

Press PREV to back

Picture 4.2.1-2

Press [2] to show preset: input current preset NO., then show current preset. As picture 4.2.1-2 shows, Press [3] to clear preset: input current preset No., then clear the current preset. As picture 4.2.1-1. press [PREV] to back.

4.2.2 Scan

Press [2] to choose scan, LCD will display as Picture 4.2.2-1 shows.

Operation

1、 scan Num:
2、 set left limit
3、 set right limit
4、 run scan
Press PREV to back

Picture 4.2.2-1

Press **【1】** to input scan NO.(1-4), by keyboard can set 4 scan at most.

Press **【2】** to set the left limit of scan: Operating the joystick to choose objective image, press **【ENTER】** to confirm. LCD will show " SUCCESS"
LCD will display as Picture 4.2.2-2 shows.

Press ENTER sure
Press PREV to back

Picture 4.2.2-2

As the above method, press **【3】** to set the right limit of scan.

Press **【4】** to run current scan (in keyboard only can set 1 scan). Press **【PREV】** to back

4.2.3 Pattern

Press **【3】** to choose pattern, LCD will display as Picture 4.2.3-1 shows.

1.pattern num:
2.set pattern
3.run pattern
Press PREV to back

Picture 4.2.3-1

Press **【1】** to input pattern No. (1-4), by keyboard can set 4 patterns at most.

Press **【2】** to program current pattern, randomly moving image and zoom in/out. The dome will record park time, magnification, focus and a series of actions, press **【1】** to start record, press "0" to stop record, LCD will display as Picture 4.3.2-2 shows.

Press 1 to start
Press 0 to stop
Press PREV to back

Picture 4.2.3-2

Press **【3】** , the dome will continuously repeat the appoint tour that you record. Press **【 PREV】** to back.

4.2.4 Tour

Press **【4】** to choose tour setting, LCD will display as Picture 4.2.4-1 shows.

1.tour num:
2.insert preset
3.run tour
Press PREV to back

Picture 4.2.4-1

Press **【1】** to input tour No. (1-6), by keyboard can set 6 tours at most.

Press **【2】** to set preset, speed and preset park time of tour. LCD will display as Picture 4.2.4-2 shows.

1.Preset num:
2.Speed
3.Dwell
Press PREV to back

Picture 4.2.4-2


Press **【1】** to input preset No. (1-80), press **【ENTER】** to confirm, the cursor jumps the second row, then input the speed (1-8) of current preset, press **【ENTER】** to confirm, the cursor jumps the third row, to input the park time (1-60s) of current preset, press **【ENTER】** to confirm, LCD will show "SUCCESS". LCD will display again as picture 4.2.4-2 shows, can continuously set 6 tours. Press **【PREV】** to back.

Press **【3】** to run tour. As picture 4.2.4-1 shows.

4.3 The alarm box control

► The operation of the keyboard controlling the alarm box:

- It can be set of the alarm signal input state of the alarm input channel and of the preset number of the channel.
- It can be set if the alarm input channel will respond the alarm input.
- It can be set that the alarm input channel are restoration mode (Manual or Auto) and the auto-restore time.
- It can be restored of the manual restoration alarm channel.
- The keyboard still can control the camera by the alarm box. The function of the camera will be no influencing, but the objective camera ID will be determined by the DIP switch setting of the alarm control box.




Picture 4.3.1-3

Input corresponding channel number(1-8)(“0” means operation for all channels), press Enter, when the cursor jumps to the second row, to input port status that need to be set (1: ON; 0: OFF), press **【Enter】**, when the cursor jumps to the third row, to input the preset point that the alarm will turn to(“0” means operation for all presets), press **【Enter】**, the screen will display the above prompt again, it requires to set other channels, you may press **【Prev】** to back the previous menu.

4.3.1 The alarm input channel state setting and the alarm spot

1. Enter the menu


LCD display (sees to the picture4.3.1-1)



Picture 4.3.1-1

2. Press **【2】** to choose the alarm setting

LCD display(sees to the picture 4.3.1-2)



Picture 4.3.1-2

3. Press **【1】** to set the alarm input channel state and spot


LCD display (sees to picture 4.3.1-3)

4.3.2 Set alarm ON/OFF status and alarm reset time

Enter into the menu,LCD display (sees to the picture4.3.1-2)

Press **【2】** to select the alarm setting status and alarm reset time.

LCD display (sees to the picture 4.3.2-1)



Picture 4.3.2-1

At this moment, press **【1】** to open alarm function, press “0” to close alarm function, press **【 Enter】**, the cursor jumps to the second row, to input the reset time that need to modify, its numerical value switches at 0-60, if you select “0” the alarm box need to reset manually.

Press **【 Prev】** or move the joystick leftwards to go back.

4.3.3 Manually reset alarm input

Enter into the menu

LCD display (sees to the picture4.3.1-2)


Press **【2】** to select the alarm box setup

LCD display (sees to the pictures4.3.3-1)

Press **【3】** to select manually reset alarm input channel

Input the relevant channel number (1-8) then pre- ss **【Enter】** to reserve.

Press **【Prev】** or move the joystick leftwards to go back.



Input port No(1-8):

Picture 4.3.3-1


4.3.4 Resume the factory default setting

Enter the main menu

LCD display (sees to the picture 4.3.1-2) Press

【2】 to select the alarm box setting Press **【4】** to resume the factory default state

LCD display (sees to the picture 4.3.3-2)



Success!

Picture 4.3.3-2

And return automatically, carry out the function. The parameter of the alarm box will resume into the state before leaving the factory, will eliminate all sett- ings. Please use the function carefully!


4.4 Protocol Setting

Enter the menu

The screen (sees to the picture4.3.1-1)

Press **【4】** to enter the protocol setting

LCD display(sees to the picture 4.4-1)



1、 Matrix
2、 Dome
3. DVR


Picture 4.4-1

4.4.1 Pel co matrix mode

Press **【1】** to enter the PELCO matrix mode

LCD display (sees to the picture 4.4.1-1)

Press **【Enter】** and choose the protocol then return



1 、 Pelco matr lx
press prev to back


Picture 4.4.1-1

When select this mode the keyboard could be control matrix.

4.4.2 Directly control model

Press **【2】** to enter the direct control mode

LCD display (sees to the picture 4.4.2-1)



1 、 Factory protocol
2 、 Pelco-p protocol
3、 Pelco-d protocol
4、 VIDO_BO2 protocol
5、 Philips protocol
6、 Hunda protocol
7、 Dahua protocol
8、 Visca protocol

press prev to back

Picture 4.4.2-1


Press the relevant numerical key to select the relevant protocol, then go back to the previous menu.

4.4.3 DVR control model

Enter the protocol setting option menu, as

picture(4.4-1), press 3 choose the DVR control

model ,as picture:(4.4.1-1),



1. DVR
2. SDVR

Press prev to back

Picture 4.4.3-1

Inside it contain two different protocols which are common DVR and special DVR (SDVR), according to the customers use different DVR model can choose different protocol, press Enter or move the joystick right side to choose the correspond number to right protocol, the screen will display Success to show protocol set successfully.

After you set DVR control protocol, press PREV to quit the keyboard control menu, on the LCD screen, after the Protocol, it will display the DVR control protocol(DVR or SDVR), when keyboard working under the SDVR control protocol, if customers need to control the dome during the process of the control the DVR. Only press “Shift” button, then can conveniently switch the model between DVR and Keyboard directly control the dome. When switch to dome directly control model, the Protocol item on LCD screen will show protocol of keyboard and dome, and ID address switch between Camera ID DVR ID, Through PREV NEXT to choose the operation DVR and Dome ID, press PREV mean the ID number reduce 1, Press NEXT mean the ID number plus 1. When choose right protocol, Baud rate and ID number, then keyboard can control the DVR.




1. When it is DVR control model, the baud rate must be set 9600Bps.
2. All path of DVR should set protocol Pelco D4, baud rate should be 9600bps, then it can communicate with dome, if you want to control dome by SDVR.

4.5 Keyboard message display

Enter the main menu

Press **【4】** to check the keyboard message

LCD display (sees to the picture 4.5-1)



Press **【Prev】** or move the joystick leftwards to return. The keyboard message menu will display the keyboard parameter setting, the keyboard model, the Keyboard protocol and the keyboard baud rate.

4.6 Exit the keyboard menu

Enter the menu

The LCD display (sees to the picture4.2.1-11)

Press **【5】** and exit the menu directly

5. 1 RS485 Bus Basic Knowledge

► Characteristic of RS485 Bus line

As specified by RS485 standards, RS485 Bus is of half-duplex data transmission cables with characteristic impedance as $120\ \Omega$. The maximum load capacity is 32 unit loads (including main controller and controller equipment)

► Transmission distance of RS485 Bus line

When user selects the 0.56mm (24AWG) twisted pair wires as data transmission cable, the maximum theoretical transmitting distances are as follows:


If user selects thinner cables, or installs the dome in an environment with strong electromagnetic interference, or connects lots of equipment to the RS485 Bus, the maximum transmitting distance will be decreased. To increase the maximum transmitting distance, do the contrary.

Baud Rate	Maximum Distance
2400bps	1800m
4800bps	1200m
9600bps	800m
19200bps	600m


► Connection and terminal resistance

The Rs485 standards require a daisy-chain connection between the equipment. There must be termination resistance with $120\ \Omega$ impedance at both ends of the connection (refer to picture 4-1.1).

Please refer to picture 4-1.2 for simple connection. And “D” should not exceed 7m.



Picture 4-1.1




Picture 4-1.2


► Problems in practical use

In some circumstances user adopts a star configuration in practical connection. The termination resistors must be connected to the two equipments that are farther away from each other, such as equipment 1# and 15# (refer to picture 4-1.3). As the star configuration is not in conformity with the requirements of Rs485 standards, problems such as signal reflections, lower anti-interference performance arise when the cables are long in the connection. The reliability of control signals are decreased with the phenomena that the dome dose not responds to or just responds at intervals to the controller, or dose continuous operation without stop.

In such circumstances the factory will recommend the usage of Rs485 distributor. The distributor can change the star configuration connection to the mode of connection stipulated in the RS485 standards. The new connection achieves reliable data transmission (refer to picture 4-1.4)



Picture 4-1.3



Picture 4-1.4

